

Installation, Use and Maintenance Manual

Gitié - ARAY

Integrated group for outdoor installation

with absorption heat pump and condensing boiler



Revision: A
Code: D-LBR729

This manual has been drawn up and printed by Robur S.p.A.; whole or partial reproduction of this manual is forbidden.

The original is filed at Robur S.p.A.

Any use of this manual other than for personal consultation must be previously authorised by Robur S.p.A.

The rights of those who have legitimately filed the registered trademarks contained within this publication are not affected.

With the aim of continuously improving the quality of its products, Robur S.p.A. reserves the right to modify the data and contents of this manual without prior notice.

INDEX OF CONTENTS

I. INTRODUCTION.....	4		
II. SYMBOLS AND DEFINITIONS	4		
1 Key to symbols.....	4		
2 Terms and definitions.....	4		
III. WARNINGS.....	4		
1 General and safety warnings	4		
2 Conformity	6		
3 Exclusions of liability and warranty.....	6		
1 FEATURES AND TECHNICAL DATA	6		
1.1 Features	6		
1.2 Size	8		
1.3 Components	10		
1.4 Wiring diagrams	14		
1.5 Electronic boards	18		
1.6 Controls	20		
1.7 Technical characteristics.....	21		
2 TRANSPORT AND PLACEMENT	23		
2.1 Warnings	23		
2.2 Handling.....	23		
2.3 Appliance placement	24		
2.4 Minimum clearance distances.....	24		
2.5 Mounting base.....	25		
3 PLUMBING INSTALLER	25		
3.1 Warnings	25		
3.2 Plumbing system	25		
3.3 Hydraulic connections	25		
3.4 Water circulation pumps	27		
3.5 Antifreeze function.....	27		
3.6 Antifreeze liquid	27		
3.7 System water quality	28		
3.8 Water system filling	28		
3.9 Combustible gas supply	28		
3.10 GAHP-AR unit combustion products exhaust	29		
		3.11 AY00-120 unit combustion products exhaust.....	30
		3.12 Combustion products exhaust through the flue	31
		3.13 AY00-120 Unit flue gas condensate discharge.....	31
		3.14 Defrosting water drainage.....	31
4 ELECTRICAL INSTALLER	31		
4.1 Warnings	31		
4.2 Electrical systems	32		
4.3 Electrical power supply.....	32		
4.4 Adjustment and control	32		
4.5 Water circulation pumps (versions C0)	35		
5 FIRST SWITCH ON.....	36		
5.1 Preliminary checks.....	36		
6 ROUTINE OPERATION	37		
6.1 Warnings	37		
6.2 Switch on and off	37		
6.3 Signals on the display.....	37		
6.4 Electronic adjustment on the machine – Menus and parameters of the S61 board and of the AY10 board	37		
6.5 How to modify settings	39		
6.6 How to restart a locked-down unit - Reset	39		
6.7 Efficiency handbook	40		
7 MAINTENANCE	40		
7.1 Warnings	40		
7.2 Pre-emptive maintenance	40		
7.3 Scheduled routine maintenance.....	41		
7.4 Periods of inactivity.....	41		
8 DIAGNOSTICS	42		
8.1 Operative codes.....	42		
APPENDICES	45		
1 Declaration of Conformity	45		

I. INTRODUCTION

Manual



This Manual is an integral part of the unit Gitié - ARAY and must be handed to the end user together with it.

Recipients

This Manual is intended for:

- ▶ end user, for appropriate and safe use of the appliance;
- ▶ qualified installer, for correct appliance installation;
- ▶ designer, for specific information on the appliance.

Control device

In order to be able to work, the unit Gitié - ARAY needs a control device (DDC or external enables), which must be connected by the installer.

II. SYMBOLS AND DEFINITIONS

1 KEY TO SYMBOLS



DANGER



WARNING



NOTE



PROCEDURE



REFERENCE (to other document)

2 TERMS AND DEFINITIONS

Gitié ARAY Appliance/Package = equivalent terms, both used to designate the integrated package consisting of a GAHP-AR unit and a condensing boiler AY00-120.

GAHP Appliance/Unit = equivalent terms, both used to designate the gas powered absorption heat pump GAHP (Gas Absorption Heat Pump).

AY00-120 Boiler/Unit = equivalent terms, both used to designate the condensation boiler AY00-120.

CAT = Technical Assistance Centre authorised by Robur.

External enable = generic control device (e.g. thermostat, clock or any other system) equipped with a NO clean contact and used as control to start/stop the GAHP unit and the AY00-120 boiler.

DDC Control (Direct Digital Controller) = optional Robur adjustment device to control one or more Robur appliances (GAHP heat pumps, GA chillers and AY00-120 boilers) in ON/OFF mode.

RB100/RB200 Devices (Robur Box) = optional interface devices complementary to DDC, which may be used to broaden its functions (heating/cooling/DHW production service demands, and control of system components such as third party generators, adjustment valves, circulators, probes).

Thermal generator = equipment (e.g. boiler, heat pump, etc..) for heat production for heating and/or DHW.

GUE (Gas Utilization Efficiency) = efficiency index of gas chillers and heat pumps, equal to the ratio between the thermal energy produced and the energy of the fuel used (relative to LCV, lower calorific value).

First Switch-One = appliance commissioning operation which may only and exclusively be carried out by a TAC.

S61/AR11 Boards = electronic boards on the GAHP unit, to control all functions and to provide interface with other devices and with the user.

S70/AY10 Boards = electronic boards on the AY00-120 boiler, to control all functions and to provide interface with other devices and with the user.

III. WARNINGS

1 GENERAL AND SAFETY WARNINGS



Installer's qualifications

Installation must exclusively be performed by a Qualified Firm and by Skilled Personnel, with specific knowledge on heating, cooling, electrical systems and gas appliances, pursuant to the laws in force in the Country of installation.



Workmanlike Conformity Declaration

Upon completing installation, the installing firm shall issue to the owner/principal the appliance's Workmanlike Conformity Declaration, according to national/local regulations in force and the manufacturer's instructions/provisions.



Misuse

The appliance must only be used for the purposes for which it has been designed. Any other use is deemed hazardous. Incorrect use may affect operation, duration and safety of the appliance. Adhere to the manufacturer's instructions.



Hazardous situations

- ▶ Do not start the appliance in hazardous conditions, such as: gas smell, problems with the hydraulic/electrical/gas system, parts of the appliance under water or damaged, malfunctioning, disabling or bypassing control and safety devices.
- ▶ In case of danger, request assistance by skilled personnel.

- ▶ In case of danger, switch off the electrical power and gas supplies only if this can be done in total safety.
- ▶ Do not entrust children, persons with physical, sensory or mental disabilities or persons with poor knowledge and experience with use of the appliance.



Gas component seal

- ▶ Before performing any operation on gas ducting components, close the gas cock.
- ▶ Upon completing any procedure, perform the leak test according to regulations in force.



Gas smell

If you smell gas:

- ▶ Do not use electrical devices such as telephones, multimeters or other equipment that may cause sparks next to the appliance.
- ▶ Shut off the gas supply by turning the cock off.
- ▶ Disconnect electrical power supply by means of the external disconnect switch in the power supply electrical panel.
- ▶ Use a telephone away from the appliance to ask for assistance from skilled personnel.



Poisoning

- ▶ Ensure the flue gas ducts are tight and compliant with the regulations in force.
- ▶ Upon completing any procedure, ensure components are tight.



Moving parts

The appliance contains moving parts.

- ▶ Do not remove guards during operation, and in any case prior to disconnecting the power supply.



Burn hazard

The appliance contains very hot parts.

- ▶ Do not open the appliance and do not touch internal components before the appliance has cooled down.
- ▶ Do not touch the flue gas exhaust before it has cooled down.



Pressure vessels

The appliance has a sealed circuit classified as pressure vessel, the tightness of which is tested by the manufacturer.

- ▶ Do not carry out any operation on the sealed circuit or on the appliance's valves.



Water-ammonia solution

The GAHP unit uses the ammonia-water absorption cycle. The water-ammonia solution is contained in the sealed circuit. The solution is harmful for health if it is ingested, inhaled or comes in contact with the skin.

- ▶ In the event of coolant leak keep away and disconnect the power and gas supply (only if it is possible to do so with no danger).
- ▶ Request assistance from the TAC.



Electrocution hazard

- ▶ Disconnect the electrical power supply before any work/procedure on appliance components.
- ▶ For electrical connections exclusively use compliant components and according to the specifications provided by the manufacturer.
- ▶ Ensure the appliance cannot be accidentally switched back on.



Earthing

Electrical safety depends on effective earthing system, correctly connected to the appliance and installed according to the regulations in force.



Distance from combustible or flammable materials

- ▶ Do not store flammable materials (paper, solvents, paint, etc.) in the vicinity of the appliance.



Scale and corrosion

Depending on the chemical-physical features of the system water, scale or corrosion may damage the appliance (Paragraph 3.7 p. 28).

- ▶ Check system sealing.
- ▶ Avoid frequent top-ups.



Chloride concentration

The concentration of chlorides or free chlorine in the system water must not exceed the values in Table 3.2 p. 28.



Aggressive substances in air

Halogenated hydrocarbons containing chlorine and fluorine compounds cause corrosion. The supply/ventilation air of the appliance must be free from aggressive substances.



Acid flue gas condensate

- ▶ Discharge the acid condensate of combustion flue gas, as indicated in Paragraph 3.13 p. 31, in compliance with current exhaust regulations.



Switching the appliance off

- ▶ Except in the case of danger, do not disconnect the power supply to switch off the appliance, but always and exclusively act through the control device provided (DDC or external enable).
- ▶ Disconnecting the power supply while the appliance is running may cause permanent damage to internal components.



In the event of failure

- ▶ In the event of failure of the appliance and/or breakage of any component, do not attempt to repair and/or restore and immediately contact the TAC.

Operations on internal components and repairs may exclusively be carried out by a TAC, only using original parts.



Routine maintenance

Proper maintenance ensures the efficiency and good operation of the appliance over time.

- ▶ Maintenance must be performed according to the manufacturer's instructions (see Chapter 7 p. 40) and in compliance with current regulations.
- ▶ Appliance maintenance and repairs may only be entrusted to firms legally authorised to work on gas appliances and systems.
- ▶ Enter into a maintenance contract with an authorised specialised firm for routine maintenance and for servicing in case of need.
- ▶ Only use original parts.



Decommissioning and disposal

If the appliance is to be disposed of, contact the manufacturer for its disposal.



Store the Manual

This "Installation, Use and Maintenance Manual" must always accompany the appliance and must be handed to the new owner or installer in the event of sale or removal.

2 CONFORMITY

EU Directives and standards

The integrated Gitié packages comply with the requirements of the following Directives:

- ▶ UNI EN 12309-1 and 2:2000, gas absorption heat pumps and chillers with thermal capacity not exceeding 70 kW.
- ▶ Gas Directive 90/396/EEC as amended and added.
- ▶ Efficiency Directive 92/42/EEC as amended and added.
- ▶ Electromagnetic compatibility Directive 89/336/EEC as amended and added.
- ▶ Low Voltage Directive 73/23/EEC as amended and added.
- ▶ Machinery Directive 2006/42/EC.
- ▶ Pressurised Equipment Directive (PED) 97/23/EEC as amended and added.

1 FEATURES AND TECHNICAL DATA

The Gitié ARAY package consists of a heat pump GAHP-AR and a condensing boiler AY00-120.

- ▶ UNI EN 677 Specific requirements for condensing boilers with nominal thermal capacity up to 70 kW.
- ▶ EN 378 Refrigerating systems and heat pumps.
- ▶ UNI EN 483 Type C boilers with nominal thermal capacity no greater than 70 kW.

Other applicable provisions and standards

The design, installation, operation and maintenance of the systems shall be carried out in compliance with current applicable regulations, depending on the Country and location, and in accordance with the manufacturer's instructions.

In particular, regulations regarding the following shall be complied with:

- ▶ Gas systems and equipment.
- ▶ Electrical systems and equipment.
- ▶ Heating and air conditioning systems, and heat pumps.
- ▶ Environmental protection and combustion products exhaust.
- ▶ Fire safety and prevention.
- ▶ Any other applicable law, standard and regulation.

3 EXCLUSIONS OF LIABILITY AND WARRANTY



Any contractual or extra-contractual liability of the manufacturer for any damage caused by incorrect installation and/or improper use and/or failure to comply with regulations and with the manufacturer's directions/instructions shall be disclaimed.



In particular, the warranty on the appliance may be rendered void by the following conditions:

- ▶ Incorrect installation.
- ▶ Misuse.
- ▶ Failure to comply with the manufacturer's indications on installation, use and maintenance.
- ▶ Alteration or modification of the product or any part thereof.
- ▶ Extreme operational conditions or however outside of the operational ranges set forth by the manufacturer.
- ▶ Damages caused by external agents such as salts, chlorine, sulphur or other chemical substances contained in the installation water or present in the air of the installation site.
- ▶ Abnormal actions transmitted by the plant or installation to the appliance (mechanical stresses, pressure, vibrations, thermal dilations, power surges...).
- ▶ Accidental damages or due to force majeure.

1.1 FEATURES

1.1.1 GAHP-AR Unit features

Operation

Based on the thermodynamic water-ammonia absorption cycle (H₂O-NH₃), the appliance alternatively produces hot water or chilled water with (seasonal) switching of the hot/cold cycle,

using outdoor air as a renewable energy source and natural gas (or LPG) as primary energy.

The thermodynamic cycle takes place within a hermetically sealed circuit, in welded construction, perfectly tight, factory-tested, which does not require any maintenance or coolant top-ups.

Mechanical and thermo-hydraulic components

- ▶ steel sealed circuit, externally treated with epoxy paint;
- ▶ Multigas pre-mixing burner equipped with ignition and flame detection managed by an electronic control unit;
- ▶ titanium stainless steel shell-and-tube water heat exchanger, externally insulated;
- ▶ air heat exchanger with single-row finned coil, with steel pipe and aluminium fins;
- ▶ inversion valve on the cooling circuit, for use of the appliance in heating or cooling mode;
- ▶ automatic microprocessor-controlled finned coil defrosting valve;
- ▶ standard or low noise S fan (sound emission reduction).

Control and safety devices

- ▶ S61 electronic board with microprocessor, LCD display and knob;
- ▶ auxiliary AR11 electronic board;
- ▶ circuit water flow switch;
- ▶ manually reset generator limit thermostat;
- ▶ PT1000 flue gas temperature probe;
- ▶ differential flue gas pressure switch on the combustion circuit;
- ▶ sealed circuit safety relief valve;
- ▶ by-pass valve, between high and low pressure circuits;
- ▶ ionisation-based flame controller;
- ▶ gas solenoid valve with double shutter;

1.1.2 AY00-120 Unit features

Operation

The AY00-120 condensation boiler produces hot water through a plate heat exchanger on an internal closed circuit.

Table 1.1 – Versions of Gitié integrated package.

Version	Pipes	Circulating pumps	2-way motorised valves	Hydraulic circuits	Simultaneous operation
Base	4	No	No	independent	Yes
KIT/4 C1	4	Yes	No	independent	Yes
KIT/2 C0	2	No	Yes	single	No ⁽¹⁾
KIT/2 C1	2	Yes	No	single	No ⁽¹⁾

(1) In 2-pipe versions operation may only be simultaneous when the GAHP-AR unit operates in heat mode.

Mechanical and thermo-hydraulic components

- ▶ premixed multigas burner with low NO_x and CO emissions;
- ▶ stainless steel plate heat exchanger, combining a hydraulic separator;
- ▶ internal circuit expansion tank;
- ▶ automatic and manual air bleeds on the internal circuit;
- ▶ flue gas discharge duct with relevant terminal, for type B53P configuration;
- ▶ anti-freeze thermostat for the condensate drain trap resistor;

Control and safety devices

- ▶ AY10 electronic board with integrated microprocessor, display and knob;
- ▶ S70 electronic board;
- ▶ ionisation-based flame controller;
- ▶ gas solenoid valve with double shutter;
- ▶ system water antifreeze function;
- ▶ water anti-freeze protection of the machine's internal circuit;
- ▶ automatically resettable water temperature limiting thermostat;
- ▶ flue gas temperature limit thermostat (thermal fuse);
- ▶ system water differential pressure switch;
- ▶ internal machine circuit water differential pressure switch with anti-bonding function;
- ▶ pressure relief valve for internal machine circuit;

1.1.3 ARAY Integrated package features

The Gitié package is available in the following versions (Figure 1.6 p. 11):


- ▶ **Base version**
- ▶ **Version KIT/4 C1**
- ▶ **Version KIT/2 C0**
- ▶ **Version KIT/2 C1**

In 4-pipe versions units operation may be simultaneous or independent.

The Table 1.1 p. 7 shows the features of the various versions in detail.


1.2 SIZE

Figure 1.1 – Size (Standard ventilation)




Front and side views (dimensions in mm).

Figure 1.2 – Dimensions (low noise version)




Front and side views (dimensions in mm).

Figure 1.3 – 2 pipe package service plate (KIT/2 C0 and C1)

LEGEND

- A Water outlet fitting Ø 1 1/2" F
- B Water inlet fitting Ø 1 1/2" F
- C Boiler condensate drain AY00-120
- G Gas fitting Ø 3/4" M

Hydraulic/gas unions detail


Figure 1.4 – 4 pipe package service plate (base version and KIT/4 C1)

LEGEND

- A AY - Water outlet fitting Ø 1 1/4" F
- B AY - Water inlet fitting Ø 1 1/4" F
- C Boiler condensate drain AY00-120
- E GAHP/GA - Water outlet fitting Ø 1 1/4" F
- F GAHP/GA - Water inlet fitting Ø 1 1/4" F
- G Gas fitting Ø 3/4" M

Hydraulic/gas unions detail

1.3 COMPONENTS


Figure 1.5 – Internal components - front view



LEGEND

1	Fan (low noise version)	7	Oil pump
2	Flue gas drawing cap	8	Water delivery fitting: "G 1"¼ F
3	Gas valve	9	Water return fitting: "G 1"¼ F
4	Combustion air restart	10	Gas fitting
5	Blower	11	TA Probe
6	Ignition transformer		


Figure 1.6 – Version components



LEGEND

- 1 BASE Version (2 independent circuits without circulating pumps)
- 2 Kit/4 C1 (2 independent circuits with on board circulators)
- 3 Kit/2 C0 (single circuit with two 2-way motorised valves)
- 4 Kit/2 C1 (single circuit with on board circulators)


Figure 1.7 – Internal components - left side view



LEGEND

- 1 Flue gas discharge Ø 80 mm
- 2 PT 1000 Flue gas Temperature Probe
- 3 Switch on and detection electrodes
- 4 Electrical panel

Figure 1.8 – Internal components - right side view




LEGEND

- | | | | |
|---|----------------------------|---|--------------------------|
| 1 | TG Probe | 6 | Defrosting valve |
| 2 | Safety valve | 7 | Return temperature probe |
| 3 | Delivery pipe flow switch | 8 | Teva Probe |
| 4 | Delivery temperature probe | 9 | Manual air vent valve |
| 5 | Limit thermostat | | |


1.4 WIRING DIAGRAMS

Figure 1.9 – Unit GAHP-AR wiring diagram




LEGEND

GV	gas solenoid valve	TG	generator inlet temperature probe	C	condenser fan motor	SCH1	main electronic board
LS	gas flow warning lamp	TEVA	evaporator outlet temperature probe	VD	defrosting valve	SCH4	auxiliary electronic board
PSW	air pressure switch	REED	oil pump rotation sensor	PMP	oil pump motor	MRV	valve inversion gear motor
THMF	outlet water temperature probe	FL	water flow switch	PWRTR	transformer 230/24 Vac	MC	hot limit switch
THRF	inlet water temperature probe	TL	generator limit thermostat (manual reset)	CNTBOX	flame control unit	MF	cold limit switch
TCN	condenser outlet temperature probe	TF	fume temperature sensor or generator fin sensor	IGN	ignition electrodes	MA	connection terminal block
TA	ambient air temperature probe	BLW	blower motor	IGNTR	ignition transformer		
				FLS	detection electrode		
				TER	power supply terminal block		

Figure 1.10 – Gitié package wiring diagram (unit AY00-120)**LEGEND**

SCH5	electronic boards S70+AY10	TF	exhausted gas thermostat	IGN	ignition electrodes
TA	room temperature probe	PD	differential water pressure switch (internal machine circuit)	FLS	flame sensor
THPC	delivery water temperature probe (internal machine circuit)	A2	differential water pressure switch (system circuit)	CNTBOX	flame control unit
THMC	output water temperature probe (system circuit)	TL	water limit thermostat (internal machine circuit)	BLW	blower
THRC	input water temperature probe (system circuit)	P1	water circulator (internal machine circuit)	MC	230Vac power supply terminal box
TH	combustion unit limit thermostat (internal machine circuit)	LS	gas valve ON signal lamp	PWRTR	board transformer
		GV	gas solenoid valve	TG	antifreeze thermostat for syphon resistance
		IGNTR	ignition transformer	RS	syphon resistance

Figure 1.11 – Gitié package wiring diagram - base version




LEGEND

MA Terminal block
MOD.0 GAHP or ACF unit
MOD.1 unit AY00-120
SCH1 electronic board S61

SCH5 electronic boards S70+AY10
TER unit power supply terminal box
J2-J10 control jumpers of system water pumps ("closed")


Figure 1.12 – Gitié package wiring diagram with KIT/2 C0



LEGEND

MOD.0 GAHP or ACF unit
MOD.1 unit AY00-120
SCH1 electronic board S61
SCH5 electronic boards S70+AY10

TER unit power supply terminal box
J2-J10 control jumpers of system water pump ("open")
MA connection terminal block
V2V0-V2V1 motorised valves

Figure 1.13 – Gitié package wiring diagram with KIT/2 C1 or with KIT/4 C1**LEGEND**

MOD.0 GAHP or ACF unit

MOD.1 unit AY00-120

SCH1 electronic board S61

SCH5 electronic boards S70+AY10


TER unit power supply terminal box

J2-J10 control jumpers of system water pumps ("closed")

MA connection terminal block

PM0-PM1 system water pumps

A Position of pumps flow rate adjustment screw

Figure 1.14 – CAN connection between AY10 board and S61 (pre-wired in the factory)**LEGEND**

SCH5 electronic board S70+AY10

SCH1 electronic board S61

J1 Jumpers CAN-BUS on AY10 board and S61 board

A terminal node connection - (3 wires; J1 jumpers = "closed")

C terminal node connection - (3 wires; J1 jumpers = "closed")

H,L,GND data signal wires (ref. cables table)

1.5 ELECTRONIC BOARDS

GAHP-AR Unit electronic boards (S61+AR11)


The GAHP-AR Unit's electrical panel contains:

- Electronic Board S61 (Figure 1.15 p. 18), with microprocessor, it controls the appliance and displays data, messages

and operative codes. The appliance is monitored and programmed by interacting with the display and knob.


- Satellite WAR11 electronic board (Figure 1.16 p. 19), interconnected to the S61 board and located next to it, used to control the cycle switching valve and to control defrosting operations of the GAHP unit.

Figure 1.15 – Electronic board S61



LEGEND

SCH	S61 controller	SPI	not used	PUMP 230V (L, N)	oil hydraulic pump supply output
THMF	water delivery temperature probe input	P8 (GND, L, H)	CAN BUS connector	N.O. Contact	circuit water circulating pump controller terminals
THRF	water return temperature probe input	J1	CAN BUS jumper	J10	circuit water circulating pump controller jumper
TCN	condenser outlet temperature probe input	A1, A2	auxiliary inputs (not used)	FAN (BK, WH, BR)	fan output
TA	ambient air temperature probe input	TF	flue gas thermostat input	JTAG	board programming connector (SCH)
TG	generator temperature probe input (condenser input)	TL	generator limit thermostat input	ENC	knob
TA1	not used	FL	water flow switch input	JP10	6-pole flame controller connector
TA2	not used	FS5 (24V AC)	board supply input (SCH) 24 Vac	F1	fuse T 2A
SRT1	oil pump rotation sensor input	P7 (R, W, Y, O)	operation enables inputs	F2	fuse F 10A
SRT2	not used	IGN.BOX (L, N)	flame control unit supply input 230 Vac	F3	fuse T 2A
JP12	not used	MAIN 230V (L, N)	board supply input (SCH) 230 Vac	F4	fuse T 3,15A


Figure 1.16 – Controller type AR11

Main components of the satellite controller AR11

AY00-120 Unit electronic boards (S70+AY10)

The AY00-120 Unit's electrical panel contains:

- Electronic Board S70 (Figure 1.17 p. 20), with microprocessor, it controls the appliance and displays data, messages and operative codes. The appliance is monitored and programmed by interacting with the display and knob.
- AY10 Electronic board (Figure 1.17 p. 20) overlapping the S70 board.

Figure 1.17 – Series AY00-120 - electronic boards AY10+S70


LEGEND

ELEMENTS OF BOARD S70

TL	limit thermostat connector
EV	gas solenoid valve connector
LS	gas valve ON signal lamp connector
P1	flame control unit connector
TF	exhausted gas thermostat connector
PD	system water differential pressure switch
A1-A2	auxiliary connectors
J2	system water circulator control jumper
NoContact	system water circulator control terminals (max 700W)
V3V	machine circulator control terminals
MAIN 230V	electrical supply connector
IGN. BOX	ignition control unit connector

ELEMENTS OF BOARD AY10

P1	connector for blower drive
PWM	signal output

THRC	input hot water temperature connector
THMC	output hot water temperature connector
TA2-TA1	auxiliary temperature probes connector
J1	CAN BUS jumper
P8	CAN port/connector
	H=data signal high
	L=data signal low
	GND=common data signal
P7	operation enable connector
	R= common terminal
	W= Heat enable terminal
	0= terminal not used
FS5	board supply connector
F1 - F2	fuses

Main elements of electronic boards on the machine AY00-120.

1.6 CONTROLS

Control device

The appliance may only work if it is connected to a control device, selected from:

- (1) **preconfigured DDC control**
- (2) **external enables**

1.6.1 Adjustment system (1) with pre-configured DDC control

The main functions are:

- adjustment and control of the GAHP unit and AY00-120 unit in cascade (ON/OFF mode) during operation in heating mode;
- adjustment and control of the GAHP unit during operation in conditioning mode;
- parameter figures display and setting;
- hourly programming;
- climate curve control;
- diagnostics;
- reset errors;

- possibility to interface with a BMS;

DDC functionality may be widened with auxiliary Robur devices RB100 and RB200 (service requests, DHW production, Third Party generator control, probe control, system valves or circulators, ...).

1.6.2 Adjustment system (2) - control with external enables

The appliance may also be controlled via generic enable devices (e.g. thermostats, clocks, buttons, contactors...) fitted with

NO clean contacts. This system only provides elementary control (on/off, with fixed set-point temperature), without the important system functions (1). Control of the cascade between GAHP/GA and AY00-120 is left to the user.



For connection of the selected device to the appliance's electronic board please refer to Paragraph 4.4 p. 32.

1.7 TECHNICAL CHARACTERISTICS

1.7.1 ARAY Integrated package technical specifications

Table 1.2 – Technical data Gitié ARAY

TECHNICAL DATA			ARAY	
BURNER FEATURES				
Maximum thermal capacity			kW	60,1
Maximum gas consumption	G20		m3/h	6.4 ⁽¹⁾
	G25		m3/h	7.5 ⁽²⁾
	G30		kg/h	4.8 ⁽³⁾
	G31		kg/h	4.7 ⁽³⁾
HYDRAULIC FEATURES				
Water flow rate 4 pipes (max/nominal/min)		GAHP-AR	l/h	5000/3040/2500
		AY00-120	l/h	3200/2700/1500
2-pipe water flow C0 version (max/nominal/min)			l/h	8200/5700/4000
Pressure loss at nominal flow rate	base version - GAHP-AR		bar	0,300
	- AY00-120		bar	0,395
	version KIT/2 C0 simultaneous operation		bar	0,560
Residual pressure head at nominal flow rate	version KIT/4 C1 - GAHP-AR		bar	0,460
	- AY00-120		bar	0,280
	version KIT/2 C1		bar	0,200
Ambient air temperature (dry bulb)	maximum		°C	45
	minimum		°C	-20
ELECTRICAL SPECIFICATIONS				
Power supply	voltage		V	230
	TYPE			Single phase
	frequency		50 Hz supply	50
Electrical power input (nominal)	Standard fan		kW	1,085 ⁽⁴⁾⁽⁵⁾
	Low-noise fan		kW	1,115 ⁽⁴⁾⁽⁵⁾
ELECTRICAL PROTECTION RATING			IP	X5D
INSTALLATION DATA				
Sound power Lw	Standard fan		dB(A)	82,1 ⁽⁶⁾
	Low-noise fan		dB(A)	76,1 ⁽⁶⁾
Sound pressure Lp at 5 metres	Standard fan		dB(A)	60,1 ⁽⁷⁾
	Low-noise fan		dB(A)	54,1 ⁽⁷⁾
Minimum storage temperature			°C	-30
Maximum operating pressure			bar	4
Water content inside the appliance			l	6
Weight in operation/transport	Standard fan		kg	480/505
	Low-noise fan		kg	490/515
Fittings	delivery/return water (4 pipe version)		"F	11/4
	delivery/return water (2 pipe version)		"F	11/2
	gas		"M	3/4
	flue gas exhaust pipe GAHP-AR		mm	80
	flue gas exhaust pipe AY00-120		mm	80
Size	width		mm	1470
	depth		mm	1260
	height		mm	1630

Notes

(1) PCI (G20) 34.02 MJ/m³ (1013 mbar – 15 °C).

(2) PCI (G25) 29.25 MJ/m³ (1013 mbar – 15 °C).

- (3) PCI (G30/G31) 46.34 MJ/kg (1013 mbar – 15 °C)
(4) ± 10% depending on power supply voltage and absorption tolerance of electric motors.
(5) Add 280 W in versions with circulating pumps.
(6) Sound power values measured according to EN ISO 9614 standard methods.
(7) Maximum sound pressure values in free field, with directionality factor 2, obtained from sound power level in compliance with EN ISO 9614 standard.

1.7.2 GAHP-AR Unit technical data

Table 1.3 – GAHP-AR Unit technical data

TECHNICAL DATA			GAHP-AR
OPERATION WHEN HEATING			
OPERATING POINT A7W50	G.U.E. gas usage efficiency	%	140 ⁽¹⁾
	Thermal power	kW	35,30 ⁽¹⁾
Hot water delivery temperature	maximum	°C	60
	nominal	°C	50
Hot water return temperature	maximum	°C	50
	minimum temperature in continuous operation	°C	20 ⁽²⁾
Thermal capacity	nominal (1013 mbar - 15 °C)	kW	25,70
OPERATING IN COOLING MODE			
OPERATING POINT A7W50	G.U.E. gas usage efficiency	%	67 ⁽¹⁾
	Cooling output	kW	16,90 ⁽¹⁾
Inlet cold water temperature	maximum	°C	45
	minimum	°C	6
INSTALLATION DATA			
Type of installation			B23 - B53
NOx emission class			5 ^{(3)test}
NOx emission		ppm	30 ⁽³⁾⁽⁴⁾
CO emission		ppm	23 ⁽³⁾⁽⁴⁾
Fume outlet	Residual head	Pa	12
PED data			
Cooling fluid	Ammonia R717	kg	7,5
	Water H ₂ O	kg	10
Components under pressure	Generator	l	18,6
	Leveling chamber	l	11,5
	Evaporator	l	3,7
	Cooling volume transformer	l	4,5
	Cooling absorber solution	l	6,3
	Solution pump	l	3,3
Test pressure (in air)		bar g	55
Safety valve pressure calibration		bar g	32
Filling ratio		kg of NH _{3/l}	0,157
"Sealed system" tare		kg	245
Fluid group			Group 1°

Notes:

- (1) As per EN12309-2 standard assessed on actual thermal capacity. For operating conditions other than nominal, refer to the Design Manual.
(2) In transient operation, lower temperatures are allowed.
(3) Values measured with G20 (natural gas) as reference gas.
(4) NO_x and CO values are measured complying with EN 483 (combustion values at 0% of O₂)

1.7.3 AY00-120 Unit technical data

Table 1.4 – Technical specifications AY00-120

TECHNICAL DATA			AY00-120
OPERATION WHEN HEATING			
OPERATING POINT: Tm80/Tr60 and nominal thermal capacity	Available power	kW	34.4
	Efficiency	%	98.6
OPERATING POINT: Tm80/Tr60 and minimal thermal capacity	Efficiency	%	97.3
OPERATING POINT: Tm70/Tr50 and nominal thermal capacity	Efficiency	%	100,6
Efficiency classes			****
NOx emission class			5

TECHNICAL DATA			AY00-120
Hot water delivery temperature	maximum	°C	80
	minimum	°C	25
	nominal	°C	60
Hot water return temperature	maximum	°C	70
	minimum	°C	20
	nominal	°C	50
INSTALLATION DATA THERMAL YIELD			
Efficiency at MEAN thermal capacity Tm80/Tr60		%	98.3
Efficiency at MIN thermal capacity Tm80/Tr60		%	97.3
Efficiency at nominal thermal capacity Tm50/Tr30		%	104.6
Efficiency at 30% of nominal thermal capacity Tr=30°C		%	107.5
Efficiency at 30% of nominal thermal capacity Tr=47°C		%	100.3
Operational heat loss to jacket		kW	0,15
Operational heat loss to jacket		%	0.44
Operational heat loss to flue		kW	0,86
Operational heat loss to flue		%	2.54
Heat loss in off mode		kW	0,058
Heat loss in off mode		%	0,2
INSTALLATION DATA			
Type of installation		B23P-B33-B53P-C13-C33-C43-C53-C63-C83	
Maximum condensation water flow rate		l/h	5,5
Fume outlet	Residual head	Pa	100

2 TRANSPORT AND PLACEMENT

2.1 WARNINGS



Damage from transport or installation

The manufacturer shall not be liable for any damage during appliance transport and installation.



On-site inspection

- Upon arrival at the site, ensure there is no transport damage on packing, metal panels or finned coil.
- After removing the packing materials, ensure the appliance is intact and complete.



Packing

Only remove the packing after placing the appliance on site.



Do not leave parts of the packing within the reach of children (plastic, polystyrene, nails...) since they are potentially dangerous.



Weight

- The crane and lifting equipment must be suitable for the load.
- Do not stand under suspended loads.

2.2 HANDLING


Handling and lifting

- Always handle the appliance in its packing, as delivered by the factory.
- To lift the appliance use straps or slings inserted in the holes of the base (Figure 2.1 p. 24).
- Use hanging and spacing rods to avoid damaging the outer panels and finned coil (Figure 2.1 p. 24).
- Comply with safety regulations at the installation site.



In the event of handling with forklift or pallet truck comply with the handling methods shown on the packing.

Figure 2.1 – Instruction for lifting



2.3 APPLIANCE PLACEMENT



Do not install inside a room

The appliance is NOT suitable for indoor installation.

- ▶ Do not install inside a room, not even if it has openings.
- ▶ In no event start the appliance inside a room.



Unit ventilation

- ▶ The aerothermic appliance requires a large space, ventilated and free from obstacles, to enable smooth flow of air to the finned coil and free air outlet above the mouth of the fan, with no air recirculation.
- ▶ Incorrect ventilation may affect efficiency and cause damage to the appliance.
- ▶ The manufacturer shall not be liable for any incorrect choices of the place and setting of installation.

Where to install the unit

- ▶ The appliance may be installed at ground level, on a terrace or on a roof, compatibly with its size and weight.
- ▶ It must be installed outside buildings, in an area of natural air circulation, outside the dripping path of drainpipes or similar. It does not require protection from weathering.
- ▶ No obstruction or overhanging structure (protruding roofs, canopies, balconies, ledges, trees) shall interfere either with the exhaust air flowing from the top of the appliance or with the exhaust flue gas.
- ▶ The appliance's flue gas exhaust must not be immediately close to openings or air intakes of buildings, and must comply with environmental regulations.
- ▶ Do not install near the exhaust of flues, chimneys or hot polluted air. In order to work correctly, the appliance needs clean air.



Defrosting water drainage

In winter, it is normal for frost to form on the finned coil and for the appliance to perform defrosting cycles.

- ▶ To prevent overflowing and damage provide for a drainage system.

Acoustic issues

- ▶ Pre-emptively assess the appliance's sound effect in connection to the site, taking into account that building corners, enclosed courtyards, restricted spaces may amplify the acoustic impact due to the reverberation phenomenon.

2.4 MINIMUM CLEARANCE DISTANCES


Distances from combustible or flammable materials

- ▶ Keep the appliance away from combustible or flammable materials or components, in compliance with applicable regulations.

Clearances around the appliance

The **minimum clearance distances** shown in Figure 2.2 p. 25 (bar any stricter regulations) are required for safety, operation and maintenance.

Figure 2.2 – Clearances



2.5 MOUNTING BASE

Mounting base constructive features

- Place the appliance on a levelled flat surface made of fire-proof material and able to withstand its weight.

(1) - installation at ground level

- Failing a horizontal supporting base, make a flat and levelled concrete base, at least 100-150 mm larger than the appliance size per side.

(2) - installation on terrace or roof

- The structure of the building must support the total weight of the appliance and the supporting base.
- If necessary, provide a maintenance walkway around the appliance.

Anti vibration mountings

Although the appliance's vibrations are minimal, resonance phenomena might occur in roof or terrace installations.

- Use anti-vibration mountings.
- Also provide anti-vibration joints between the appliance and water and gas pipes.

3 PLUMBING INSTALLER

3.1 WARNINGS



General warnings

Read the warnings in Chapter III p. 4, providing important information on regulations and on safety.



Compliance with installation standards

Installation must comply with applicable regulations in force, based on the installation Country and site, in matters of safety, design, implementation and maintenance of:

- heating systems;
- cooling systems;
- gas systems;
- combustion products exhaust;
- flue gas condensate discharge.



Installation must also comply with the manufacturer's provisions.

3.2 PLUMBING SYSTEM

Primary and secondary circuit

- In many cases it is advisable to divide the hydraulic system into two parts, primary and secondary circuit, uncoupled by

a hydraulic separator, or possibly by a tank that also acts as inertial volume/thermal flywheel.

Minimum water content

High thermal inertia is conducive to efficient appliance operation. Very short ON/OFF cycles are to be avoided.

- If necessary, provide for an inertial volume, to be suitably sized (see design manual).

3.3 HYDRAULIC CONNECTIONS

4-pipe version hydraulic connections

on the right, at the bottom, connection plate (Figure 1.4 p. 9).

- A (= out) 1"1/4 F - WATER OUTPUT AY (m = delivery AY to the system)
- B (= in) 1"1/4 F - WATER INPUT AY (r = return AY from the system)
- E (= out) 1"1/4 F - WATER OUTPUT GAHP/GA (m = delivery GAHP/GA to the system)
- F (= in) 1"1/4 F - WATER INPUT GAHP/GA (r = return GAHP/GA from the system)

2-pipe version hydraulic connections

on the right, at the bottom, connection plate (Figure 1.3 p. 9).

- A (= out) 1"1/2 F - WATER OUTPUT (m = delivery to the system)
- B (= in) 1"1/2 F - WATER INPUT (r = return from the system)

Hydraulic pipes, materials and features

- Use pipes for heating/cooling systems, protected from weathering, insulated for thermal dispersion.



Pipe cleaning

Before connecting the appliance, accurately clean the water and gas piping and any other system component, removing any residue.

Minimum components of the primary hydraulic circuit (2-pipe version or each of the two circuits GAHP-GA/AY00-120 of the 4-pipe versions)

Always provide, near the appliance:

on water piping, both output and input (m/r)

- 2 ANTIVIBRATION JOINTS on water fittings;

- 2 PRESSURE GAUGES;

- 2 BALL VALVES for shutting off;

on the input water piping (r)

- WATER CIRCULATION PUMP with thrust towards the unit (for the C0 version - without circulating pumps)

- 1 DIRT SEPARATOR FILTER


- 1 FLOW REGULATOR VALVE

on the output water piping (m)


- 1 SAFETY VALVE (3 bar);

- 1 EXPANSION TANK of the individual unit.

Figure 3.1 – Hydraulic diagram Gitié KIT/2 C0 with storage



INDICATIVE DIAGRAM NOT VALID FOR EXECUTION PURPOSES

Figure 3.2 – Hydraulic diagram Gitié KIT/4 C0 DHW

INDICATIVE DIAGRAM NOT VALID FOR EXECUTION PURPOSES

3.4 WATER CIRCULATION PUMPS

3.4.1 Versions C0

Circulation pumps (flows and heads) must be selected and installed based on pressure losses of hydraulic circuits (piping + components + exchange terminals + appliance).

For the appliance's pressure losses refer to Table 1.2 p. 21.

Circulation pumps will be controlled at constant flow.



For pump sizing in the version KIT/2 C0 also consider the alternate operation case.

For electrical connections of the pumps refer to Paragraph 4.5 p. 35.

3.4.2 Versions C1

Water circulation pumps are supplied on the appliance.

For available water flow and residual head features refer to Table 1.2 p. 21.

3.5 ANTIFREEZE FUNCTION

Active antifreeze self-protection

The appliance is equipped with an active antifreeze self-protection system to prevent freezing. The antifreeze function, if activated, automatically starts primary circulation pumps and, if required, the burner too (for the AY00-120 unit and when the GAHP-AR unit is in heating operation mode), when the outside temperature approaches zero.

The active antifreeze self-protection is only effective if the power and gas supplies are assured. Otherwise, antifreeze liquid might be required.

3.6 ANTIFREEZE LIQUID



Precautions with glycol

The manufacturer disclaims any liability for any damage caused by improper glycol use.

- Always check product suitability and its expiry date with the glycol supplier. Periodically check the product's preservation state.
- Do not use car-grade antifreeze liquid (without inhibitors), nor zinc-coated piping and fittings (incompatible with glycol).

Glycol modifies the physical properties of water (density, viscosity, specific heat...).

- Size the piping, circulation pumps and thermal generators accordingly.

With automatic system water filling, a periodic check of the glycol content is required.



With high glycol percentage (> 20...30%)

If the glycol percentage is $\geq 30\%$ (for ethylene glycol) or $\geq 20\%$ (for propylene glycol) the TAC must be alerted before First Switch-On.

Type of antifreeze glycol

- **Inhibited type glycol** is recommended to prevent oxidation phenomena.



Electrical and gas continuity

Glycol effects

The Table 3.1 p. 28 shows, indicatively, the effects of using glycol depending on the %.

Table 3.1 – Technical data for filling the hydraulic circuit

GLYCOL %	10	15	20	25	30	35	40
WATER-GLYCOL MIXTURE FREEZING TEMPERATURE	-3°C	-5°C	-8°C	-12°C	-15°C	-20°C	-25°C
PERCENTAGE OF INCREASE IN PRESSURE DROPS	--	6%	8%	10%	12%	14%	16%
LOSS OF EFFICIENCY OF UNIT	--	0,5%	1%	2%	2,5%	3%	4%

3.7 SYSTEM WATER QUALITY



Responsibility of the user/operator/installer

The installer, operator and user are bound to assure system water quality (Table 3.2 p. 28). Failure to comply with the manufacturer's guidelines may affect operation, integrity and duration of the appliance, voiding the warranty.

System water features

Free chlorine or water hardness may damage the appliance. Adhere to the chemical-physical parameters in Table 3.2 p. 28 and the regulations on water treatment for residential and industrial heating systems.

Table 3.2 – Chemical and physical parameters of water

CHEMICAL AND PHYSICAL PARAMETERS OF WATER IN HEATING/COOLING SYSTEMS		
PARAMETER	UNIT OF MEASUREMENT	ALLOWABLE RANGE
pH	\	>7 ⁽¹⁾
Chlorides	mg/l	< 125 ⁽²⁾
Total hardness (CaCO ₃)	°f	< 15
	°d	< 8,4
Iron	mg/kg	< 0,5 ⁽³⁾
Copper	mg/kg	< 0,1 ⁽³⁾
Aluminium	mg/l	< 1
Langelier's index	\	0-0,4
HARMFUL SUBSTANCES		
Free chlorine	mg/l	< 0,2 ⁽³⁾
Fluorides	mg/l	< 1
Sulphides		ABSENT

- 1 with aluminium or light alloys radiators, pH must also be lower than 8 (in compliance with applicable rules)
 2 value referred to the maximum water temperature of 80 °C
 3 in compliance with applicable rules

Water topping up

The chemical-physical properties of the system's water may alter over time, resulting in poor operation or excessive topping up.

- ▶ Ensure there are no leaks in the water system.
- ▶ Periodically check the chemical-physical parameters of the water, particularly in case of automatic topping up.



Chemical conditioning and washing

Water treatment/conditioning or system washing carried out carelessly may result in risks for the appliance, the system, the environment and health.

- ▶ Contact specialised forms or professionals for water treatment or system washing.
- ▶ Check compatibility of treatment or washing products with operating conditions.

- ▶ Do not use aggressive substances for stainless steel or copper.
- ▶ Do not leave washing residues.

3.8 WATER SYSTEM FILLING

How to fill up the system



After completing all water, electrical and gas connections:

1. Pressurise (at least 1.5 bar) and vent the hydraulic circuit.
2. Let water flow (with appliance off).
3. Check and clean the filter on the return pipe.
4. Repeat items 1, 2 and 3. until the pressure has stabilised (1.5 bar).

3.9 COMBUSTIBLE GAS SUPPLY

Gas fitting

▶ 3/4" M

on the right, at the bottom, **connection plate** (Figure 1.3 p. 9 and 1.4 p. 9).

- ▶ Install an anti-vibration joint between the appliance and the gas piping.

Obligatory shut-off valve

- ▶ Provide a gas shut-off valve (manual) on the gas supply line, to isolate the appliance when required.
- ▶ Perform connection in compliance with applicable regulations.

Gas pipes sizing

The gas pipes must not cause excessive load losses and, consequently, insufficient gas pressure for the appliance.

Supply gas pressure

The appliance's gas supply pressure, both static and dynamic, must comply with Table 3.3 p. 29, with tolerance $\pm 15\%$.

Table 3.3 – Network gas pressure

Product categories	Countries of destination	Gas supply pressure						
		G20 [mbar]	G25 [mbar]	G30 [mbar]	G31 [mbar]	G25.1 [mbar]	G27 [mbar]	G2,350 [mbar]
II _{2H3B/P}	AL, BG, CY, CZ, DK, EE, FI, GR, HR, IT, LT, MK, NO, RO, SE, SI, SK, TR	20		30	30			
	AT, CH	20		50	50			
II _{2H3P}	AL, BG, CZ, ES, GB, HR, IE, IT, LT, MK, PT, SI, SK, TR	20			37			
	RO	20			30			
II _{2ELL3B/P}	DE	20	20	50	50			
II _{2Ei3P}	FR	20	25		37			
II _{2H53B/P}	HU	25		30	30	25		
II _{2E3P}	LU	20			50			
II _{2L3B/P}	NL		25	50	50			
II _{2E3B/P}	PL	20		37	37			
II _{2ELwLs3B/P}		20		37	37		20	13
II _{2ELwLs3P}		20			37		20	13
I _{2E(S);13P}	BE	20	25		37			
I _{3P}	IS				30			
I _{2H}	LV	20						
I _{3B/P}	MT			30	30			
I _{3B}				30				



Non conforming gas pressure (Table 3.3 p. 29) may damage the appliance and be hazardous.

Vertical pipes and condensate

- ▶ Vertical gas pipes must be fitted with drain trap and discharge of the condensate that may form inside the pipe.
- ▶ If necessary, insulate the piping.

LPG pressure reducers

With LPG the following must be installed:

- ▶ a first stage pressure reducer, close to the liquid gas tank;
- ▶ a second stage pressure reducer, close to the appliance.

3.10 GAHP-AR UNIT COMBUSTION PRODUCTS EXHAUST



Compliance with standards

The appliance is approved for connection to a combustion products exhaust duct for the types shown in Table 1.3 p. 22.


Flue gas exhaust fitting

- ▶ Ø 80 mm (with gasket), on the left (Figure 3.3 p. 30).

Flue gas exhaust kit

The appliance is supplied with flue gas exhaust kit, to be fitted by the installer, including (Figure 3.3 p. 30):

- ▶ 1 Ø 80 flue gas exhaust pipe length 750 mm (H);
- ▶ 1 "T" connector (I);
- ▶ 1 condensate trap (L);
- ▶ 1 terminal (E);
- ▶ 1 clamp for fixing pipe (F) to left side panel;
- ▶ 4 pipe clamps (G);
- ▶ 1 condensate drain hose fitting and silicone hose (M).

Figure 3.3 – Fume outlet


How to install the flue gas kit



Figure 3.3 p. 30:

1. Remove the front panel (N);
2. Place the clamp with spacer (F) in the suitable hole on the left panel of the appliance;
3. Fasten the condensate trap (L) on the "T" fitting (I);
4. Remove the protection cover;
5. Fasten the "T" fitting (I) on the appliance's flue gas exhaust (Ø 80 mm);
6. Fasten the flue gas exhaust pipe (H) (L= 750 mm) onto the "T" fitting (I);
7. Block the flue gas exhaust pipe (H) in the clamp with spacer (F);
8. Fit the terminal (E) on the flue gas exhaust pipe (H);
9. Fix the condensate drain pipe fitting and the relevant silicon tube (M);
10. Replace the front panel (N).

The appliance is approved for connection to a combustion products exhaust duct for the types shown in Table 1.4 p. 22.

Flue gas exhaust fitting

- Ø 80 mm
- in the upper part (Figure 3.3 p. 30).

Flue gas exhaust kit

The appliance is supplied with flue gas exhaust kit, to be fitted by the installer, including (Figure 3.3 p. 30).

- 1 terminal;
- 1 extension pipe Ø 80 mm, length 209 mm;
- 1 rain cover;

How to install the flue gas kit



Figure 3.3 p. 30:

1. Fit the terminal (A) onto the pipe (B);
2. Fit the rain cover (C) onto the pipe (B);
3. Remove the protection cover located on the upper panel;
4. Fit the rain cover/pipe/terminal assembly onto the flanged fitting (D) and place the rain cover.

3.11 AY00-120 UNIT COMBUSTION PRODUCTS EXHAUST



Compliance with standards



The protection cover has the purpose of preventing ingress of water and/or foreign matter into the appliance before installation of the flue gas kit. It is therefore important to remove the protection only upon completing installation of the kit.

3.12 COMBUSTION PRODUCTS EXHAUST THROUGH THE FLUE

If necessary, the appliance may be connected to a flue.

- ▶ To size the flue refer to Table 1.4 p. 22, Table 1.3 p. 22 and Design Manual.
- ▶ If the flue gas exhaust of the GAHP and that of the AY00-120 boiler are connected to a single flue, it is mandatory to install a flap valve on the exhaust of each.

The flue must be designed, sized, tested and constructed by a skilled form, with materials and components complying with the regulations in force in the country of installation.

- ▶ Always provide a socket for flue gas analysis, in an accessible position.



To avoid corrosion phenomena, convey the discharge of GAHP-AR acid condensate to the base of the flue gas discharge duct.

3.13 AY00-120 UNIT FLUE GAS CONDENSATE DISCHARGE

The AY00-120 unit is a condensing boiler which therefore produces condensation water from combustion fumes.



Condensate acidity and exhaust regulations

The fume condensation water contains aggressive acid substances.

Refer to applicable regulations in force for condensate exhaust and disposal.

- ▶ If required, install an acidity neutraliser of adequate capacity (Table 1.4 p. 22).



Do not use gutters to discharge the condensate.

Do not discharge the fume condensate water in gutters, due to the risk of materials corrosion and ice formation.

In the AY00-120 unit the fitting for flue gas condensate discharge is located on the right side of the appliance at the service plate (Figure 1.3 p. 9 and Figure 1.4 p. 9).

- ▶ The condensate discharge pipe must be connected to a suitable discharge manifold.
- ▶ The junction between the pipe and the manifold must remain visible.

Flue gas condensate discharge manifold

If necessary the condensate discharge manifold may be in common between the 2 units the Gitié package consists of.

To make the condensate discharge manifold:

- ▶ Size the ducts for maximum condensation capacity (Table 1.4 p. 22).
- ▶ Use plastic materials resistant to acidity pH 3-5.
- ▶ Provide for min. 1% slope, i.e. 1 cm for each m of the length (otherwise a booster pump is required).
- ▶ Prevent freezing.
- ▶ Dilute, if possible, with domestic waste water (bathrooms, washing machine, dish washers...), basic and neutralising.

3.14 DEFROSTING WATER DRAINAGE



Defrosting

In winter, frost may form on the finned coil and the appliance performs defrosting cycles.

Collection basin and drainage system

- ▶ Provide for a collection basin or containment rim and a discharge system of the defrosting water, to avoid overflowing, icing and damage.

4 ELECTRICAL INSTALLER

4.1 WARNINGS



General warnings

Read the warnings in Chapter III p. 4, providing important information on regulations and on safety.



Compliance with installation standards

Installation must comply with applicable regulations in force, based on the installation Country and site, in matters of safety, design, implementation and maintenance of electrical systems.

Installation must also comply with the manufacturer's provisions.



Live components

After placing the appliance in the final position, and prior to making electrical connections, ensure not to work on live components.



Earthing

- ▶ The appliance must be connected to an effective earthing system, installed in compliance with regulations in force.
- ▶ It is forbidden to use gas pipes as earthing.



Cable separation

Keep power cables physically separate from signal ones.



Do not use the power supply switch to turn the appliance on/off.

- ▶ Never use the external disconnecter (GS) to turn the appliance on and off, since it may be damaged in the long run (occasional black outs are tolerated).
- ▶ To turn the appliance on and off, exclusively use the suitably provided control device (DDC or external enable).



Control of water circulation pumps

In C0 versions the water circulation pumps of the primary hydraulic circuit must mandatorily be controlled by the unit's electronic boards. It is not admissible to start/stop circulating pumps with no enable from the appliance.

4.2 ELECTRICAL SYSTEMS

Electrical connections must provide:

- ▶ (a) power supply (Paragraph 4.3 p. 32);
- ▶ (b) control system (Paragraph 1.6 p. 20).


How to perform connections



All electrical connections of the Gitié package must be made in the Electrical Panel of boiler AY 00-120 (Figure 1.7 p. 12):

1. Ensure the appliance's Electrical Panel is not live.
2. Remove the front panel of the boiler and the cover of the Electrical Panel.
3. Insert the wires through the suitable holes located on the rear panel of the boiler (Figure 4.1 p. 32).
4. Make the connections by running the wires through the suitable cable glands in the Electrical Panel.
5. Close the Electrical Panel and fit the front panel back on.

Figure 4.1 – Electrical cables routing holes position



LEGEND

A Holes for electrical cable routing

4.3 ELECTRICAL POWER SUPPLY

Power supply line

Provide (by the installer) a protected single phase line (230 V 1-N 50 Hz) with:

- ▶ 1 three-pole cable type FG7(O)R 3Gx1.5;
- ▶ 1 two-pole switch with two 8 A fuses type T, (GS) or one 10A magnetothermic breaker.



The switches must also provide disconnect capability, with min contact opening 4 mm.


How to connect the power supply



To connect the three-pole power supply cable (Figure 4.2 p. 32):

1. Connect the three lead-in wires to the terminal (TER) in the electrical panel on the machine.
2. Provide the earth lead-in wire longer than live ones (last to be torn in the event of accidental pulling).

Figure 4.2 – Package power supply wiring diagram



Connecting the appliance to the power supply mains (230V 1N - 50Hz)

4.4 ADJUSTMENT AND CONTROL

Control systems, options (1) (2)

Two separate adjustment systems are provided, each with specific features, components and diagrams (see Paragraph 1.6 p. 20):

- ▶ System (1), with **DDC control** (with CAN-BUS connection).
- ▶ System (2), with **external enables**.

4.4.1 Control with DDC

CAN-BUS communication network

The CAN-BUS communication network, implemented with the cable of the same name, makes it possible to connect and

remotely control one or more Robur appliances with the DDC control device.

It entails a certain number of serial nodes, distinguished in:

- intermediate nodes, in variable number;
- terminal nodes, always and only two (beginning and end);

Each component of the Robur system, appliance (GAHP, GA, AY, Gitié, ...) or control device (DDC, RB100, RB200, CCI, ...), corresponds to a node, connected to two more elements (if it is an

intermediate node) or to just one other element (if it is a terminal node) through two/one CAN-BUS cable section/s, forming an open linear communication network (never star or loop-shaped).

CAN-BUS signal cable

The DDC controller is connected to the appliance through the CAN-BUS signal cable, shielded, compliant to Table 4.1 p. 33 (admissible types and maximum distances).

Table 4.1 – CAN BUS cables type

CABLE NAME	SIGNAL / COLOR			MAX LENGTH	Note
Robur					Ordering Code OCV0008
ROBUR NETBUS	H= BLACK	L= WHITE	GND= BROWN	450 m	
Honeywell SDS 1620					In all cases the fourth conductor should not be used
BELDEN 3086A	H= BLACK	L= WHITE	GND= BROWN	450 m	
TURCK type 530					
DeviceNet Mid Cable					
TURCK type 5711	H= BLUE	L= WHITE	GND= BLACK	450 m	
Honeywell SDS 2022					
TURCK type 531	H= BLACK	L= WHITE	GND= BROWN	200 m	


For lengths ≤ 200 m and max 4 nodes (e.g. 1 DDC + 1 Gitié), a simple 3x0.75 mm shielded cable may even be used.

How to connect the CAN BUS cable to the package



To connect the CAN-BUS cable to the AY10 electronic board (Paragraph 1.5 p. 18), located in the Electrical Panel inside the AY 00-120 unit, Figure 4.3 p. 34, Details A and B:

1. access the Electrical Panel (procedure Paragraph 4.2 p. 32)
2. connect the CAN-BUS cable to terminals GND + L and H (shielding/earthing + two signal conductors) of the AY10 board;
3. place the Jumper J1, of the AY10 board, OPEN;
4. connect the DDC to the CAN-BUS cable to terminals GND + L and H (shielding/earthing + two signal conductors) of the DDC;
5. the CAN connection between the AY10 board and the S61 board is pre-wired (Figure 1.14 p. 17);

Figure 4.3 – CAN-BUS connection between Gitié and DDC

4.4.2 Control with external enables

How to connect external enables



Connection of external enables is effected on the terminal block located in the Electrical Panel inside the AY00-120 unit.

If you wish the heating enables of the two units to be simultaneous follow the connection diagram shown in Figure 4.4 p. 34. Should you wish the enables of the two units to be separate in heating mode too follow the connection diagram shown in Figure 4.5 p. 35.



Figure 4.4 – Connection diagram of simultaneous hot external enables


Figure 4.5 – Connection diagram of separate hot external enables

4.5 WATER CIRCULATION PUMPS (VERSIONS C0)




System water pumps will be controlled at constant flow.

4.5.1 4-pipe versions

Figure 4.6 – System pump connection diagram Gitie package base version (P)

The diagram in Figure 4.6 p. 35 is for pumps < 700 W. For pumps > 700 W it is necessary to add a control relay and arrange Jumpers J10 and J2 OPEN.

4.5.2 2-pipe versions

Figure 4.7 – System pump connection diagram Gitié package 2 pipe version (KIT/2 C0)

5 FIRST SWITCH ON



First Switch-On entails checking/adjusting the combustion parameters and must be carried out ONLY by a Robur TAC. In this stage, NEITHER the user NOR the installation technician is authorised to perform such operations, under penalty of voiding the warranty.

5.1 PRELIMINARY CHECKS

Preliminary checks for First Switch-on

Upon completing installation, before contacting the TAC the installer is bound to check:

- ▶ water-heating, electrical and gas systems suitable for the required capacities and equipped with all safety and control devices required by the regulations in force;
- ▶ absence of leaks in the water and gas systems;
- ▶ type of gas for which the appliance is designed;
- ▶ supply gas pressure complying with the values of Table 3.3 p. 29, with max tolerance $\pm 15\%$;
- ▶ Power supply mains complying with the appliance's rating plate data;
- ▶ appliance correctly installed, according to the manufacturer's instructions;
- ▶ system installed in a workmanlike manner, according to national and local regulations.

Abnormal or hazardous installation situations

Should any abnormal or hazardous installation situations be found, the TAC shall not perform First Switch-on and the appliance shall not be commissioned.

These situations may be:

- ▶ appliance installed inside a room;
- ▶ failed compliance with minimum clearances;
- ▶ insufficient distance from combustible or flammable materials;
- ▶ conditions that do not warrant access and maintenance in safety;
- ▶ appliance switched on/off with the main switch, instead of the control device provided (DDC, or external enable);
- ▶ appliance defects or faults caused during transport or installation;
- ▶ gas smell;
- ▶ non-compliant mains gas pressure;
- ▶ non-compliant flue gas exhausts;
- ▶ all situations that may involve operation abnormalities or are potentially hazardous.

Non-compliant system and corrective actions

Should the TAC find any non conformities, the user/installer is bound to perform any corrective procedures required by the TAC.

After performing the remedial actions (the installer's responsibility), if the TAC deems that safety and conformity conditions are in place, "First Switch-on" may be effected.

6 ROUTINE OPERATION

This section is for the end user.

6.1 WARNINGS



General warnings

Prior to using the appliance carefully read the warnings in Chapter III p. 4, providing important information on regulations and on safety.



First Switch-on by TAC

First Switch-on may exclusively be carried out by a Robur TAC (Paragraph 5 p. 36).



Never power the appliance off while it is running

NEVER power the appliance off while it is running (except in the event of danger, Chapter p. 4), since the appliance or system might be damaged.

6.2 SWITCH ON AND OFF



Routine switching on/off

The appliance may exclusively be switched on/off by means of the suitably provided control device (DDC or external enable).



Do not Switch On/Off with the power supply switch

Do not switch the appliance on/off with the power supply switch. This may be harmful and dangerous for the appliance and for the system.



Inspections before switching on

Before switching on the appliance, ensure that:

- ▶ gas cock open;
- ▶ appliance electrical power supply (main switch (GS) ON);
- ▶ DDC power supply (if any);
- ▶ water circuit ready.

How to switch on/off

- ▶ If the appliance is controlled by a DDC, case (1), refer to the relevant manual.
- ▶ If the appliance is controlled by external enables (e.g. thermostat, clock, button, ... with clean contact NO), case (2), the appliance is switched on/off by the ON/OFF positions of the external control devices.

After switching on with the control, in normal operating conditions, the appliance starts/stops automatically according to the user's needs, supplying water at the programmed temperature.



Although the external enable is in the "ON" position, this does not mean the appliance will start immediately, but it will only start when there are actual service demands.

6.3 SIGNALS ON THE DISPLAY

4 digit display

The S61 board and the AY10 board (Figures 6.1 p. 38 and 6.2 p. 38) are fitted with a 4-digit display, visible through the sight glass of the respective front panels.

- ▶ When the appliance is powered on, all the LEDs switch on for 3 sec, then the board name is displayed.
- ▶ After another 15 sec, the appliance is ready to operate.

Signals in normal operation

- ▶ During normal operation, water temperature values alternate on the display: output, input and the difference between the two.

Signals in the event of fault

In the event of fault the display flashes indicating an operative code (first letter on the display: "E" = error, or "U" = warning)

- ▶ If it is only a temporary warning, the appliance may continue working.
- ▶ If it is a permanent error or warning the appliance stops (Table 8.1 p. 42 and Table 8.2 p. 44)


6.4 ELECTRONIC ADJUSTMENT ON THE MACHINE – MENUS AND PARAMETERS OF THE S61 BOARD AND OF THE AY10 BOARD




Firmware

The instructions on the use of the S61 electronic board concern the **firmware version 3.027**.

The instructions on the use of the AY10 electronic board concern the **firmware version 3.106**.

Figure 6.1 – GAHP-AR unit electronic board

LEGEND

- A 4 digit display
- B Knob
- C CAN port

Figure 6.2 – AY00-120 unit on-board electronics

LEGEND

- A 4 digit display
- B Knob
- C CAN port

Controllers AY10 and S70.

Display

The 4-digit displays of the boards (Detail A in Figure 6.1 p. 38 and in Figure 6.2 p. 38) are as follows:

- ▶ the **first digit** on the left, green) indicates the menu number (e.g. "0.", "1.", "2.", ... "8.");
- ▶ the **last three digits** (on the right, red) indicate a **code** or a **value** for a parameter, among those included in the selected menu (e.g. "_6" "_20", "161").

(e.g. menu+parameter "1._6", "2._20", "3.161").

Knob

One of the following actions may be done with the board knob (Detail B in Figure 6.1 p. 38 and in Figure 6.2 p. 38):

- ▶ Enter the menu list (by pressing the first time);

- ▶ Scroll the menu list, or a series of parameters in a menu (by turning);
- ▶ Select a menu or a parameter (by pressing);
- ▶ Modify and confirm the setting of a parameter (turning and pressing);
- ▶ Execute a command (by pressing);
- ▶ Exit a menu and go back to the higher level by selecting the letter "E" which is displayed at the end of the menu list or of a series of parameters in a menu.

The letter "E" is displayed at the end of the menu list or of a series of parameters in a menu, and indicates the exit to go back to the higher level by pressing the knob.

Menus and Parameters

The menus may be display only (functional data or parameters), display and setting (parameters) or control (reset)

Menu for the user (but for the installer and TAC as well)

- ▶ the menu "0.", display only, for functional data detected in real time;
- ▶ the menu "1.", display only, for current values of appliance parameters;
- ▶ menu "2.", control, to execute flame control unit reset operations, reset errors (Paragraph 6.6 p. 39);
- ▶ menu "3.", display and setting, to set the value of some system parameters (e.g. water set point temperature); the values are initialised by the TAC at First Switch-On.

It is accessed without password.

Menu for the installer or TAC (not accessible to the user)

- ▶ Menu "4.", "5." and "6." are password-protected. These are specific sections, exclusively intended for skilled personnel (installer or TAC). For information see the technical Assistant Manual.
- ▶ Menu "7." is display only and intended for the manufacturer.
- ▶ Menu "8." is empty, it may be selected but not used.



Special key for the knob

- ▶ To access the menus and parameters of the boards, use the special standard supplied key (fastened on the gas pipe above the electrical panel). The key allows the knob to be operated through the suitable hole in the Electrical Panel cover, operating safely away from live components.
- ▶ Always keep the key for future uses.

How to access the Menus and Parameters

Before Starting:

1. Power supply switch "ON";
2. Display of the board showing in sequence the detected water temperature data (if the appliance is in normal operation), or the flashing malfunction and failure codes (if the appliance is in failure).



To access the menus and parameters of the board, proceed as follows (see also Figure 6.1 p. 38 and Figure 6.2 p. 38).

1. Remove the front panel by removing the fixing screws.
2. Remove the cover of the electrical panel to access the board knob.
3. Act on the knob by means of the special key through the suitable hole.
4. Press the knob once to display the menus: the first menu is displayed, "0." (= menu 0).
5. Turn the knob clockwise to scroll down and display the other/subsequent menus; the menu numbers will be displayed in order, "1.", "2.", ... , "6." ... or "E" (= exit).
6. Select the menu of interest (e.g. display "2.____" = menu 2) by pressing the knob; the first parameter code will be displayed, in menu order (e.g. display "2._20" = parameter 20 in menu 2).
7. Turn the knob clockwise to scroll down the other parameters in the menu; the codes will be displayed in order (e.g. display "2._20", "2._21" ... "2._25" = parameters 20, 21, ... 25 in menu 2), or letter "E" (= exit) at the end of the list.
8. Select the parameter of interest (e.g. with code 161 in menu 3) by pressing the knob; the figure previously assigned to the parameter will be displayed, read only or to be set (e.g.

the figure "45" for parameter 161 in menu 3 = water temperature set-point at 45 °C); if instead of a figure/setting it is a command, a flashing code is displayed (e.g. "reS1" for the flame block reset command).

9. Press the knob to reconfirm the figure; or rotate the knob to modify the figure, and press at the end to confirm or set the new figure; if however, it is a matter of controlling an appliance operation, press the knob to execute it.
10. To exit a parameter menu or the menu list and go back to the higher level, turn the knob to display the letter "E" for exit, then press the knob again.
11. Place the cover back on the electrical panel opening and fit the appliance's front panel back on.

6.5 HOW TO MODIFY SETTINGS



Modify settings via the DDC

If the device is connected to the DDC control, refer to the relevant manual to modify settings.

How to raise/lower the water temperature set-point

The water temperature set-point establishes the delivery temperature to the system (water output from the appliance), or return from the system (water input in the appliance). The temperature is pre-set by the TAC upon First Switch-On.



If the appliance is not connected to a DDC control, to raise/lower the water temperature set-point with the S61 or AY10 board, proceed as follows:

1. Access menu 3 under parameter "water temperature set-point" (for heating parameter 161, for conditioning parameter 75) by rotating and pressing the knob; the display must show "3.161" or "3._75" (procedure Paragraph 6.4 p. 37);
2. Display the parameter value by pressing the knob; the previously set value is displayed (from 10 to 65 °C for parameter 161, from 4.5 to 25 °C for parameter 75); to reconfirm the pre-existing value press the knob again, otherwise go to point 3.
3. Turn the knob to modify the value, increasing or decreasing it, and press it to set the new value;
4. Exit menu 3, and from the menu list, by selecting and pressing letter "E" twice, and go back to the normal display of detected temperature data.



Do not modify complex settings

Specific technical and system knowledge is required for complex settings. Contact a TAC.

6.6 HOW TO RESTART A LOCKED-DOWN UNIT - RESET

Fault signals on the display

In the event of locked-down appliance, an operative code flashes on the display (first green figure on the left, letter "U" = warning or "E" = error).

- ▶ To restart the appliance you must know and perform the procedure concerning the issue signalled and identified by the code (Paragraph 8.1 p. 42).
- ▶ Only act if you are familiar with the issue and with the procedure (technical expertise and professional qualifications might be required).

- If you do not know the code, the problem, or the procedure, or you do not have sufficient skills, and in any case of doubt, contact the TAC.

Locked-down appliance

An external procedure (reset or repair) is required due to an appliance fault or problem with the system.

- A reset may be enough for a temporary and provisional anomaly.
- For a fault or breakdown, alert the maintenance technician or TAC.

Reset

There are two options for resetting a fault:

- (1) If the appliance is connected to a DDC you may act through the control device, as described in the relevant manual.
- (2) You may act directly from the S61 board and/or the AY10 board as described below (if the appliance is controlled with external enable, this is the only option).

How to perform reset from the S61 and AY10 boards

To perform the reset directly from the board:

1. **Reset flame block:** access Menu 2 under Parameter "_20", (for units AY00-120) or Parameter "__0" (for unit GAHP-AR), turning and pressing the knob; "2._20"/"2.__0" must be displayed (procedure Paragraph 6.4 p. 37);

2. **Reset other errors:** access Menu 2 under Parameter "_21", (for units AY00-120) (for the S61 board) or Parameter "__1" (for unit GAHP-AR), turning and pressing the knob; "2.__0"/"2.__1" must be displayed (procedure Paragraph 6.4 p. 37);
3. Press the knob to display the flashing reset request (e.g. "reS1" to reset flame block).
4. Press the knob again (the second time) to perform the reset; the reset request stops flashing, then "2._XX" is displayed again (e.g. "2._20"). The reset operation has been performed.
5. Exit menu 2 and the menu list, by selecting and pressing letter "E" twice, and go back to the normal display of detected temperature data.

6.7 EFFICIENCY HANDBOOK

For increased appliance efficiency:

- Keep the finned coil clean;
- Adjust maximum water temperature to the actual system requirement;
- Reduce repeated switch-ons to the minimum (low loads);
- Program appliance activation for actual periods of use;
- Keep water and air filters on the water and ventilation systems clean.

7 MAINTENANCE

7.1 WARNINGS



Correct maintenance prevents problems, assures efficiency and keeps running costs low.



Maintenance operations described herein may exclusively be performed by the TAC or skilled maintenance technician.



Any operation on internal components may exclusively be performed by the TAC.



Before performing any operation, switch off the appliance by means of the control device (DDC or external enable) and wait for the end of the switching off cycle, then disconnect power and gas supply, by acting on the electrical disconnecter and gas cock.



The efficiency checks and every other "check and maintenance operation" (see Tables 7.1 p. 40 and 7.2 p. 41) must be performed with a frequency according to current regulations or, if more restrictive, according to the provisions set forth by the manufacturer, installer or TAC.



Responsibility for efficiency checks, to be carried out for the aims of restricting energy consumption, lies with the system manager.



Heavy-duty use

If the unit is subject to heavy duty use (for example in process plants or in other conditions of continuous operation), maintenance operations must be more frequent.

7.2 PRE-EMPTIVE MAINTENANCE

- For pre-emptive maintenance, comply with the recommendations in Table 7.1 p. 40.

Table 7.1

GUIDELINES FOR THE PREVENTIVE MAINTENANCE OPERATIONS					
Check of the unit	GAHP-A	GAHP-GS/WS	AY	ACF	GAHP-AR
Visually check of the general condition of the unit and of its air heat exchanger (1)	✓			✓	✓
Check the correct operation of the device used for monitoring the water flow	✓	✓	✓	✓	✓
Check the % value of CO ₂	✓	✓	✓		
check gas pressure to the burners				✓	✓

GUIDELINES FOR THE PREVENTIVE MAINTENANCE OPERATIONS					
Check that the condensate discharge is clean [If necessary, frequency of the maintenance operation must be increased]	√	√	√		
Replace the belts after 6 years or 12,000 hours of operation	√	√		√	√
Check/restore the pressure of the primary hydronic circuit			√		
Check/restore the air pressure inside of the expansion vessel of the primary hydronic circuit			√		
Check for every DDC or CCI	DDC or CCI				
Check that the plant is able to achieve the setpoint temperature	√				
Download the historical events	√				

1 - It is suggested the cleaning of the air heat exchanger once every 4 years [the optimal frequency of this operation is in any case a consequence of the installation site].

7.3 SCHEDULED ROUTINE MAINTENANCE

For scheduled routine maintenance, perform the operations in Table 7.2 p. 41, at least once every 2 years.

Table 7.2

SCHEDULED MAINTENANCE OPERATIONS	TO BE PERFORMED AT LEAST ONE EVERY TWO YEARS				
Check of the unit	GAHP-A	GAHP-GS/WS	AY	ACF	GAHP-AR
Clean the combustion chamber	√*	√*	√	√	√*
Clean the burner	√*	√*	√	√	√*
Clean the electrodes of ignition and flame sensing	√	√	√	√	√
Check that the condensate discharge is clean	√	√	√		
Replace the silicone gasket between the front plate and the exchanger			√		

*Only in case the analysis of combustion products is non-compliant

7.4 PERIODS OF INACTIVITY



Avoid emptying the water system

Emptying the system may cause damage due to corrosion of the water pipes.



Deactivate the system in winter

Should you intend to stop the appliance in the winter season, ensure at least one of the following conditions:

1. antifreeze function active (Paragraph 3.5 p. 27);
2. sufficient antifreeze glycol (Paragraph 3.6 p. 27).

Prolonged periods of inactivity

- Should you foresee to leave the appliance inactive for a long period of time, disconnect it from the electrical and gas mains. These operations must be performed by Qualified Personnel.

How to deactivate the appliance for long periods of time

1. Switch the appliance off (Paragraph 6.2 p. 37).
2. Only when the appliance is completely off, power it off with the main switch/disconnect switch (Detail GS in Figure 4.2 p. 32).
3. Close the gas valve

4. If necessary, add water with glycol (if the appliance is disconnected from the power and gas mains, the active antifreeze protection is missing, Paragraph 3.5 p. 27).

How to reactivate the appliance after long periods of inactivity

Before reactivating the appliance, the operator/maintenance technician of the system must first of all:

- Check whether any maintenance operations are required (contact the TAC; see Paragraphs 7.2 p. 40 and 7.3 p. 41).
- Check content and quality of the water in the system, and if necessary top it up (Paragraphs 3.8 p. 28, 3.7 p. 28 and 3.6 p. 27).
- Ensure the flue gas exhaust duct is not obstructed, and that the condensate drain is clean.



After completing the above checks:

1. Open the gas cock and ensure there are no leaks; should gas smell be noticed, close the gas cock again, do not switch any electrical devices on and request intervention by Skilled Personnel.
2. Power on with the main power supply switch (GS, Figure 4.2 p. 32).
3. Switch on the appliance by means of the provided control device (DDC or external enable, Paragraph 4.4 p. 32).

8 DIAGNOSTICS

8.1 OPERATIVE CODES

Table 8.1 – Operative Codes GAHP-AR

CODES	DESCRIPTION	Warning (u)	Error (E)
600	FAULT ON RESET CIRCUIT OF FLAME CONTROL UNIT	NA	<ul style="list-style-type: none"> Power cycle the appliance. If the code persists, shows up again or in case of doubt, contact the TAC.
601	GENERATOR LIMIT THERMOSTAT TRIP	Contact authorised Technical Assistance	
602	FLUE GAS THERMOSTAT TRIP	Contact authorised Technical Assistance	
603	COLD WATER ANTI-FREEZE THERMOSTAT TRIPPED	Reset is automatic when the triggering condition ceases.	NA
604	INSUFFICIENT VENTILATION	Reset occurs automatically 20 minutes after the code is generated.	Reset may be performed from the DDC or from the S61 board (menu 2, parameter 1). If the code persists, shows up again or in case of doubt, contact the TAC.
605	AMBIENT TEMPERATURE EXCEEDING OPERATIVE LIMITS	NA	Reset is automatic when the triggering condition ceases.
606	AMBIENT TEMPERATURE LOWER THAN OPERATIVE LIMITS	Non-blocking Warning (informative code). The code is reset automatically when the triggering condition ceases.	NA
607	GENERATOR TEMPERATURE HIGH	Reset is automatic when the triggering condition ceases.	Reset may be performed from the DDC or from the S61 board (menu 2, parameter 1). If the code persists, shows up again or in case of doubt, contact the TAC.
608	FLAME CONTROL UNIT ERROR	NA	Contact authorised Technical Assistance
610	INSUFFICIENT WATER FLOW	Reset is automatic when the triggering condition ceases.	<ul style="list-style-type: none"> Check and clean water filters on the system. Check for air in the system. Check water flow pump. Power cycle the appliance. Reset may be performed from the DDC or from the S61 board (menu 2, parameter 1). If the code persists, shows up again or in case of doubt, contact the TAC.
611	INSUFFICIENT ROTATION OF OIL PRESSURE PUMP	Reset occurs automatically 20 minutes after the code is generated.	Reset may be performed from the DDC or from the S61 board (menu 2, parameter 1). If the code persists, shows up again or in case of doubt, contact the TAC.
612	FLAME CONTROL UNIT ARREST	Reset is automatic up to 4 attempts (in about 5 minutes).	<ul style="list-style-type: none"> Gas supply check. Reset may be performed from the DDC or from the S61 board (menu 2, parameter 0). If the code persists or in case of doubt, contact the TAC.
616	FAULTY OUTLET WATER TEMPERATURE PROBE	NA	Reset may be performed from the DDC or from the S61 board (menu 2, parameter 1). If the code persists, shows up again or in case of doubt, contact the TAC.
617	FAULTY INLET WATER TEMPERATURE PROBE	NA	Reset may be performed from the DDC or from the S61 board (menu 2, parameter 1). If the code persists, shows up again or in case of doubt, contact the TAC.
618	FAULTY CONDENSER OUTLET TEMPERATURE PROBE	NA	Reset is automatic in case of switching from "cold" to "hot" mode. Reset may be performed from the DDC or from the S61 board (menu 2, parameter 1). If the code persists, shows up again or in case of doubt, contact the TAC.
620	FAULTY GENERATOR TEMPERATURE PROBE	NA	Reset may be performed from the DDC or from the S61 board (menu 2, parameter 1). If the code persists, shows up again or in case of doubt, contact the TAC.
626	GENERATOR FIN TEMPERATURE SENSOR MALFUNCTION	NA	Reset may be performed from the DDC or from the S61 board (menu 2, parameter 1). If the code persists, shows up again or in case of doubt, contact the TAC.
628	GAS SOLENOID VALVE EXCITED DURING FLAME CONTROLLER ARREST	NA	<ul style="list-style-type: none"> Power off the appliance. Contact authorised Technical Assistance.
629	GAS SOLENOID VALVE WITHOUT ELECTRICAL POWER	Reset occurs automatically if the gas solenoid valve switches on again within 10 minutes (with central flame control unit on).	Reset may be performed from the DDC or from the S61 board (menu 2, parameter 1). If the code persists, shows up again or in case of doubt, contact the TAC.
630	GENERATOR FINS TEMPERATURE HIGH	Reset is automatic when the triggering condition ceases.	Reset may be performed from the DDC or from the S61 board (menu 2, parameter 1). If the code persists, shows up again or in case of doubt, contact the TAC.

CODES	DESCRIPTION	Warning (u)	Error (E)
631	HOT WATER TEMPERATURE EXCEEDING OPERATIVE LIMITS	<ul style="list-style-type: none"> Check configuration of other heat generators on the system. Check water flow. Check system thermal load. Reset is automatic when the triggering condition ceases.	NA
632	COLD WATER TEMPERATURE LOWER THAN OPERATIVE LIMITS	<ul style="list-style-type: none"> Check configuration of other chillers on the system. Check water flow. Check system's chilling load. Reset is automatic when the triggering condition ceases.	NA
644	FAULTY EVAPORATOR TEMPERATURE PROBE	NA	Reset is automatic in case of switching from "hot" to "cold" mode. Reset may be performed from the DDC or from the S61 board (menu 2, parameter 1). If the code persists, shows up again or in case of doubt, contact the TAC.
646	HIGH HOT INLET WATER TEMPERATURE	<ul style="list-style-type: none"> Check configuration of other heat generators on the system. Reset is automatic and occurs if the generating condition ceases with circulating pump on or 20 minutes after the code is generated with circulating pump off.	NA
647	HOT INLET WATER TEMPERATURE LOWER THAN OPERATIVE LIMITS	Reset occurs automatically when the generating cause resolves or 430 seconds after the code is generated.	Reset is automatic in case of switching from "hot" to "cold" mode. Reset may be performed from the DDC or from the S61 board (menu 2, parameter 1). If the code shows up again or in case of doubt contact the TAC.
648	HIGH HOT WATER DIFFERENTIAL TEMPERATURE	<ul style="list-style-type: none"> Check water flow. Reset occurs automatically 20 minutes after the code is generated.	Reset is automatic in case of switching from "hot" to "cold" mode. Reset may be performed from the DDC or from the S61 board (menu 2, parameter 1). If the code shows up again or in case of doubt contact the TAC.
649	SATELLITE BOARD NOT PRESENT	NA	Contact authorised Technical Assistance.
651	ANTIFREEZE FUNCTION ACTIVATED - COLD SIDE	Non-blocking Warning (informative code). The code clears automatically when antifreeze function execution ends.	NA
652	DEFROSTING FUNCTION ACTIVATED	Non-blocking Warning (informative code). The code clears automatically when execution of defrosting ends.	NA
654	INVERSION OPPOSITE		Reset is automatic in case of new switching and discontinuation of the generating cause. If the code shows up again or in case of doubt contact the TAC.
655	INVERSION UNKNOWN		Reset is automatic in case of new switching and discontinuation of the generating cause. If the code shows up again or in case of doubt contact the TAC.
656	INVERSION UNCERTAIN		Reset is automatic in case of new switching and discontinuation of the generating cause. If the code shows up again or in case of doubt contact the TAC.
478	HIGH HOT OUTLET WATER TEMPERATURE	Reset is automatic in case of switching from "hot" to "cold" mode. Reset is automatic when the triggering condition ceases.	NA
479	DEFROST FUNCTION ACTIVATED - HOT SIDE	Non-blocking Warning (informative code). The code clears automatically when antifreeze function execution ends.	NA
80/680	INCOMPLETE OR INVALID PARAMETERS	Contact authorised Technical Assistance.	
681	INVALID P0 PARAMETERS	Reset is automatic when the triggering condition ceases.	Contact authorised Technical Assistance.
682	INVALID P1 PARAMETERS	Reset is automatic when the triggering condition ceases.	Contact authorised Technical Assistance.
683	SIMULTANEOUS HOT AND COLD REQUEST	Reset is automatic when the triggering condition ceases.	NA
684	FAULTY TRANSFORMER CONNECTION OR 24 V AC FUSES	NA	Contact authorised Technical Assistance.
685	INCORRECT MODULE TYPES	NA	Contact authorised Technical Assistance.
686	FAULTY BOARD, ROM	NA	Contact authorised Technical Assistance.
687	FAULTY BOARD, pRAM	NA	Contact authorised Technical Assistance.
688	FAULTY BOARD, xRAM	NA	Contact authorised Technical Assistance.
689	FAULTY BOARD, REG.	NA	Contact authorised Technical Assistance.
690	FAULTY AMBIENT TEMPERATURE PROBE	NA	Reset may be performed from the DDC or from the S61 board (menu 2, parameter 1). If the code persists, shows up again or in case of doubt, contact the TAC.
691	CONTROLLER DEFECTIVE	NA	Contact authorised Technical Assistance.

NA: Not Applicable

Table 8.2 – Operative Codes AY00-120

CODES	DESCRIPTION	Warning (u)	Error (E)
100	FAULT ON RESET CIRCUIT OF FLAME CONTROL UNIT	NA	<ul style="list-style-type: none"> Power cycle the appliance. If the code persists, shows up again or in case of doubt, contact the TAC.
101	THERMOSTAT TRIP INTERNAL CIRCUIT LIMIT	Contact authorised Technical Assistance	
102	FLUE GAS THERMOSTAT AND/OR INTERNAL EXCHANGER THERMOSTAT TRIP	Contact authorised Technical Assistance	
103	HEATING BOARD (S70) ABSENT	NA	Contact authorised Technical Assistance
105	AMBIENT TEMPERATURE EXCEEDING OPERATIVE LIMITS	NA	Reset is automatic when the triggering condition ceases.
106	AMBIENT TEMPERATURE LOWER THAN OPERATIVE LIMITS	NA	The code is reset automatically when the triggering condition ceases.
107	SYSTEM CIRCUIT WATER PRESSURE SWITCH TRIP WITH SYSTEM IN COLD MODE	Reset is automatic when the triggering condition ceases.	NA
112	FLAME CONTROL UNIT ARREST	Reset is automatic up to 4 attempts (in about 5 minutes).	<ul style="list-style-type: none"> Gas supply check. Reset may be performed from the DDC or from the AY10 board (menu 2, parameter 20). If the code persists or in case of doubt, contact the TAC.
127	FAULTY INTERNAL CIRCUIT WATER PRESSURE SWITCH OR INSUFFICIENT INTERNAL CIRCUIT WATER FLOW	Reset is automatic when the triggering condition ceases.	Reset may be performed from the DDC or from the AY10 board (menu 2, parameter 21). If the code persists or in case of doubt, contact the TAC.
128	GAS SOLENOID VALVE EXCITED DURING FLAME CONTROLLER ARREST	NA	<ul style="list-style-type: none"> Power off the appliance. Contact authorised Technical Assistance.
129	GAS SOLENOID VALVE WITHOUT ELECTRICAL POWER	Reset occurs automatically if the gas solenoid valve switches on again within 10 minutes (with central flame control unit on).	Reset may be performed from the DDC or from the AY10 board (menu 2, parameter 21). If the code persists, shows up again or in case of doubt, contact the TAC.
135	FAULTY INTERNAL CIRCUIT DELIVERY TEMPERATURE PROBE	NA	Reset may be performed from the DDC or from the AY10 board (menu 2, parameter 21). If the code persists, shows up again or in case of doubt, contact the TAC.
136	BLOWER FAULT	Reset occurs automatically 20 minutes after the code is generated.	Reset may be performed from the DDC or from the AY10 board (menu 2, parameter 21). If the code persists, shows up again or in case of doubt, contact the TAC.
175	INSUFFICIENT SYSTEM CIRCUIT WATER FLOW	Reset is automatic when the triggering condition ceases.	<ul style="list-style-type: none"> Check and clean water filters on the system. Check for air in the system. Check water flow pump. Power cycle the appliance. Reset may be performed from the DDC or from the AY10 board (menu 2, parameter 21). If the code persists, shows up again or in case of doubt, contact the TAC.
176	FAULTY SYSTEM CIRCUIT DELIVERY TEMPERATURE PROBE	NA	Reset may be performed from the DDC or from the AY10 board (menu 2, parameter 21). If the code persists, shows up again or in case of doubt, contact the TAC.
177	FAULTY SYSTEM CIRCUIT RETURN TEMPERATURE PROBE	NA	Reset may be performed from the DDC or from the AY10 board (menu 2, parameter 21). If the code persists, shows up again or in case of doubt, contact the TAC.
178	HIGH HOT OUTLET WATER TEMPERATURE	Reset is automatic when the triggering condition ceases.	NA
179	DEFROST FUNCTION ACTIVATED	Non-blocking Warning (informative code). The code clears automatically when antifreeze function execution ends.	NA
80	INCOMPLETE OR INVALID PARAMETERS	Contact authorised Technical Assistance.	
81	INVALID P0 PARAMETERS	Reset is automatic when the triggering condition ceases.	Contact authorised Technical Assistance.
82	INVALID P1 PARAMETERS	Reset is automatic when the triggering condition ceases.	Contact authorised Technical Assistance.
84	FAULTY TRANSFORMER CONNECTION OR 24 V AC FUSES	NA	Contact authorised Technical Assistance.
85	INCORRECT MODULE TYPES	NA	Contact authorised Technical Assistance.
86	FAULTY BOARD, ROM	NA	Contact authorised Technical Assistance.
87	FAULTY BOARD, pRAM	NA	Contact authorised Technical Assistance.
88	FAULTY BOARD, xRAM	NA	Contact authorised Technical Assistance.
89	FAULTY BOARD, REG.	NA	Contact authorised Technical Assistance.
90	FAULTY AMBIENT TEMPERATURE PROBE	NA	Reset may be performed from the DDC or from the AY10 board (menu 2, parameter 21). If the code persists, shows up again or in case of doubt, contact the TAC.
91	CONTROLLER DEFECTIVE	NA	Contact authorised Technical Assistance.

NA: Not Applicable

APPENDICES

1 DECLARATION OF CONFORMITY

Figure 1



EC - DECLARATION OF CONFORMITY



Manufacturer : Robur S.p.A.
Address : Via Parigi 4/6
City, Country : Verdellino/Zingonia 24040 (Bg), Italy

This is to declare that the ROBUR Gas Absorption Heat Pump (GAHP) are in conformity with the following EC-Directives:

2006/42/EC Machinery Directive with subsequent amendments and integrations.

2004/108/EC Electromagnetic Compatibility with subsequent amendments and integrations.
Tested and examined according to the following norms: EN55014-1, EN55014-2, EN61000-3-2, EN61000-3-3, EN62233.

2006/95/EC Low Voltage Directive with subsequent amendments and integrations.
Tested and examined according to the following norms: EN50165, EN60335-2-102, EN60335-1.

2009/142/EC Gas Appliance Directive with subsequent amendments and integrations.
Tested and examined according to the following norms: EN 12309-1, EN 12309-2, EN 483.
As proved with EC certification number 0964, issued by KIWA Italia S.p.A Via G. Carducci, 5 Milan-Italy

97/23/EC Pressure Equipment Directive with subsequent amendments and integrations.
As proved with EC Certification number 1370 of all the components under pressure of the IIIrd category, issued by BUREAU VERITAS Italia S.p.A. Via Miramare, 15 Milan-Italy

Jvan Benzoni
R&D Director
Robur S.p.A.

coscienza ecologica caring for the environment

Robur S.p.A. tecnologie avanzate per la climatizzazione advanced heating and cooling technologies www.robur.it robur@robur.it
via Parigi 4/6 24040 Verdellino/Zingonia (BG) Italy T +39 035 888111 F +39 035 884165 capitale sociale € 2.028.000,00 i.v. iscritta al Registro
Imprese di Bergamo n. 154968 codice fiscale/partita iva 00373210160 V.A.T. code IT 00373210160 società soggetta all'attività di direzione e
coordinamento di Fin Robur S.p.A. di Benito Guerra & C.

Robur mission

Robur is dedicated to dynamic progression
in research, development and promotion
of safe, environmentally-friendly, energy-efficiency products,
through the commitment and caring
of its employees and partners.



Robur Spa
advanced climate
control technologies
Via Parigi 4/6
24040 Verdellino/Zingonia (Bg) Italy
T +39 035 888111 F +39 035 884165
www.robur.it robur@robur.it

